```
/*PHOTORESISTOR Use a photoresistor (light sensor) to control the brightness of a LED.*/
// As usual, we'll create constants to name the pins we're using.
// This will make it easier to follow the code below.
const int sensorPin = 0;
const int ledPin = 9;
// We'll also set up some global variables for the light level:
int lightLevel, high = 0, low = 1023;
void setup()
  // We'll set up the LED pin to be an output.
 // (We don't need to do anything special to use the analog input.)
 pinMode(ledPin, OUTPUT);
void loop()
  // Just as we've done in the past, we'll use the analogRead()
  // function to measure the voltage coming from the photoresistor
  // resistor pair. This number can range between 0 (0 Volts) and
  // 1023 (5 Volts), but this circuit will have a smaller range
  // between dark and light.
  lightLevel = analogRead(sensorPin);
  // We now want to use this number to control the brightness of
  // the LED. But we have a problem: the analogRead() function
  // returns values between 0 and 1023, and the analogWrite()
  // function wants values from 0 to 255.
  // We can solve this by using two handy functions called map()
  // and constrain(). Map will change one range of values into
  // another range. If we tell map() our "from" range is 0-1023,
  // and our "to" range is 0-255, map() will squeeze the larger
  // range into the smaller. (It can do this for any two ranges.)
  // lightLevel = map(lightLevel, 0, 1023, 0, 255);
  // Because map() could still return numbers outside the "to"
  // range, (if they're outside the "from" range), we'll also use
  // a function called constrain() that will "clip" numbers into
  // a given range. If the number is above the range, it will reset
  // it to be the highest number in the range. If the number is
  // below the range, it will reset it to the lowest number.
  // If the number is within the range, it will stay the same.
  // lightLevel = constrain(lightLevel, 0, 255);
  // Here's one last thing to think about. The circuit we made
  // won't have a range all the way from 0 to 5 Volts. It will
  // be a smaller range, such as 300 (dark) to 800 (light).
  // If we just pass this number directly to map(), the LED will
  // change brightness, but it will never be completely off or
  // completely on.
```

```
// You can fix this two ways, each of which we'll show
  // in the functions below. Uncomment ONE of them to
  // try it out:
 manualTune(); // manually change the range from light to dark
  //autoTune(); // have the Arduino do the work for us!
  // The above functions will alter lightLevel to be cover the
  // range from full-on to full-off. Now we can adjust the
  // brightness of the LED:
 analogWrite(ledPin, lightLevel);
 // The above statement will brighten the LED along with the
  // light level. To do the opposite, replace "lightLevel" in the
 // above analogWrite() statement with "255-lightLevel".
 // Now you've created a night-light!
void manualTune()
  // As we mentioned above, the light-sensing circuit we built
  // won't have a range all the way from 0 to 1023. It will likely
 // be more like 300 (dark) to 800 (light). If you run this sketch
 // as-is, the LED won't fully turn off, even in the dark.
  // You can accommodate the reduced range by manually
 // tweaking the "from" range numbers in the map() function.
 // Here we're using the full range of 0 to 1023.
  // Try manually changing this to a smaller range (300 to 800
  // is a good guess), and try it out again. If the LED doesn't
  // go completely out, make the low number larger. If the LED
 // is always too bright, make the high number smaller.
 // Remember you're JUST changing the 0, 1023 in the line below!
 lightLevel = map(lightLevel, 0, 1023, 0, 255);
  lightLevel = constrain(lightLevel, 0, 255);
  // Now we'll return to the main loop(), and send lightLevel
 // to the LED.
void autoTune()
  // As we mentioned above, the light-sensing circuit we built
  // won't have a range all the way from 0 to 1023. It will likely
 // be more like 300 (dark) to 800 (light).
 // In the manualTune() function above, you need to repeatedly
  // change the values and try the program again until it works.
  // But why should you have to do that work? You've got a
 // computer in your hands that can figure things out for itself!
  // In this function, the Arduino will keep track of the highest
  // and lowest values that we're reading from analogRead().
  // If you look at the top of the sketch, you'll see that we've
```

```
// initialized "low" to be 1023. We'll save anything we read
// that's lower than that:
if (lightLevel < low)</pre>
  low = lightLevel;
// We also initialized "high" to be 0. We'll save anything
// we read that's higher than that:
if (lightLevel > high)
 high = lightLevel;
// Once we have the highest and lowest values, we can stick them
// directly into the map() function. No manual tweaking needed!
// One trick we'll do is to add a small offset to low and high,
// to ensure that the LED is fully-off and fully-on at the limits
// (otherwise it might flicker a little bit).
lightLevel = map(lightLevel, low+30, high-30, 0, 255);
lightLevel = constrain(lightLevel, 0, 255);
// Now we'll return to the main loop(), and send lightLevel
// to the LED.
```