SAFETY OPERATING PROCEDURES

Milling Machine

DO NOT use this machine unless the technician has instructed you in its safe use and operation and has given permission.



Safety glasses must be worn at all times in work areas.



CSA footwear must be worn at all times in work areas.



Rings and jewellery must not be worn.



Long and loose hair must be contained.



Close fitting/protective clothing must be worn.



Gloves must not be worn when using this machine.

PRE-OPERATIONAL SAFETY CHECKS

- 1. Ensure no slip/trip hazards are present in workspaces and walkways.
- 2. Locate and ensure you are familiar with the operation of the ON/OFF starter and E-Stop (if fitted).
- 3. Do not leave equipment on top of the machine.
- 4. Check that machine guards are in position.
- 5. Ensure cutter is in good condition and securely mounted.
- 6. Check coolant delivery system to allow for sufficient flow of coolant.
- 7. Faulty equipment must not be used. Immediately report suspect machinery.

OPERATIONAL SAFETY CHECKS

- 1. Keep clear of moving machine parts.
- 2. Never leave the machine running unattended.
- 3. Follow correct clamping procedures- keep overhangs as small as possible and check work piece is secure.
- 4. Set the correct speed to suit the cutter diameter, the depth of cut and the material.
- 5. Before making adjustments and measurements or before cleaning swarf accumulations switch off and bring the machine to a complete standstill.

HOUSEKEEPING

- 1. Switch off the machine.
- 2. Remove milling cutters and store them safely.
- 3. Leave the machine and work area in a safe, clean and tidy state.

POTENTIAL HAZARDS

- Sharp cutters
- Moving components hair/clothing entanglement
- Eye injury
- Skin irritation
- Metal splinters and burrs
- Flying debris

This SOP does not necessarily cover all possible hazards associated with the machine and should be used in conjunction with other references

It is designed to be used as an adjunct to teaching Safety Procedures and to act as a reminder to users prior to machine use

Date of last review Signature