

# EMERGENCY EYEWASH SHOWER COMBINATION UNITS WEEKLY INSPECTION

## WEEKLY REQUIREMENTS

Initial and date in the corresponding box verifying the emergency eyewash/shower combination unit was checked for the following:

- ✓ The pathway to the station is clear of all obstructions.
- ✓ The shower/eyewash fixture is free of obstructions in all directions.
- ✓ There are no visible leaks from plumbing components.
- ✓ The unit is clean.
- ✓ To test the emergency shower, flush water until stagnant water from the dead leg is removed. Repeat for eyewash.
- ✓ To test the eyewash simultaneously with emergency shower ensuring both have adequate flow.
- ✓ Check that the flow of water once activated, can be used without requiring the use of the operator's hands.
- ✓ Do a visual inspection of water flow and pattern to ensure proper coverage.
- ✓ Ensure flap covers are closed.
- ✓ Check that signage to the emergency eyewash/shower equipment is visible.

## IF PROBLEMS ARE EVIDENT

1. Report the issues to your supervisor immediately.
2. Notify Plant Operations at ext. 33793.
3. Lockout/Tagout the station until necessary repairs are carried out.
4. Ensure no hazardous materials are used until repairs are completed.

Scan [the QR code](#) to watch a video demonstration on how to use eye wash stations and safety showers during emergency spills.



<b>Year:</b>		<b>Week 1</b>		<b>Week 2</b>		<b>Week 3</b>		<b>Week 4</b>		<b>Week 5</b>	
<b>Building</b>	<b>Room</b>	<b>Initial</b>	<b>Day</b>	<b>Initial</b>	<b>Day</b>	<b>Initial</b>	<b>Day</b>	<b>Initial</b>	<b>Day</b>	<b>Initial</b>	<b>Day</b>
January											
February											
March											
April											
May											
June											
July											
August											
September											
October											
November											
December											